



75214

MITSUBISHI ENDEAVOR


www.uhaul.com 7/18/2012

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH:  
GROSS LOAD CAPACITY WHEN USED AS A WEIGHT DISTRIBUTION HITCH:3,500BS. TRAILER WEIGHT &  
5,000BS. TRAILER WEIGHT &600BS. TONGUE WEIGHT.  
1,300BS. TONGUE WEIGHT**\*\*\*DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.\*\*\***

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

## Parts List

ITEM	QTY	PART NUMBER	DESCRIPTION
1	7	M10-1.25 x 35	HEX BOLT
2	7	3/8"	CONICAL TOOTHED WASHER



HITCH WEIGHT: 29 LBS.

## INSTALL TIME

PROFESSIONAL: 30 MINUTES

NOVICE (DIY): 60 MINUTES

## INSTALL NOTES:

- NO DRILLING REQUIRED
- LOWER EXHAUST REQUIRED

## INSTALLATION STEPS

- 1) Temporarily lower muffler by removing rear rubber hanger.
- 2) Place hitch into position. Fit to inside and bottom of frame rails, one side at a time. Align hitch with M10 weldnut in frame. (Note: Driver side should be positioned first.)
- 3) Install M10 fasteners - seven locations.
- 4) Torque all M10 fasteners to 48 lb.-ft. Re-attach rubber exhaust hanger.

**PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.**

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.