

CATALOG NUMBER.....217230  
 APPLICATION .....Geo Spectrum Sedan,  
 HITCH CAPACITY .....1000 pounds gross trailer weight 100 pounds maximum tongue load  
 OR the maximum load specified by the vehicle manufacturer;  
 WHICHEVER IS LESS.

PLEASE NOTE: This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and regulation V.E.S.C. V-5.

1. Measure and mark the car's centerline on the rear bumper. Mark and cut away plastic fascia just where hitch bumper bracket must fit to steel inner bumper. See diagram.
2. Hitch should now fit directly onto steel inner bumper and tire well. Make certain hitch is centered and square with the car with enough bumper/ball clearance. Mark bumper and tire well for hitch mounting screws. Center punch and drill for 3/8" diameter mounting screws.
3. Mount hitch to car using the fasteners called out in the diagram. Be certain to use flat washers as shown opposite the hitch inside bumper and tire well. Access to place elbow screws and washers (2) inside bumper is through existing access holes in face of inner bumper.
4. Final tighten all fasteners as specified on reverse of these instructions. Recheck all fasteners occasionally for tightness.

#### FASTENERS:

- ① (2) 3/8 x 1 1/2" screw  
 (2) 3/8" fender washer  
 (2) 3/8" lock washer  
 (2) 3/8" hex nut
- ② (2) 3/8 x 1 1/2" elbow screw  
 (2) 3/8" flat washer  
 (2) 3/8" lock washer  
 (2) 3/8" hex nut

