## TRAILER HITCH MOUNTING INSTRUCTIONS

CATALOG NUMBER	217270
	Ford Fiesta,
	1500 pounds gross trailer weight 150 pounds maximum tongue load
	OR the maximum load specified by the vehicle manufacturer;
	WHICHEVER IS LESS

PLEASE NOTE:

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and regulation V.E.S.C. V-5.

- 1. Remove spare tire and any material in cargo well.
- 2. Position the hitch against underside of floor in cargo area and bottom edge of rear bumper as shown in diagram. Support the hitch in place making sure it is centered and square on the car. Adjust fore/aft for enough hitch ball/ bumper clearance.
- 3. Using hitch as a template mark and centerpunch for four holes at floor and two holes at bumper. Drill these holes for 3/8" diameter screws.
- 4. Fasten hitch to car using fasteners 1 and 2. Note that fender and flat washers are placed INSIDE cargo well and bumper OPPOSITE the hitch.
- 5. Final tighten all fasteners as specified on reverse of these instructions. Recheck all fasteners occasionally for tightness.

## **FASTENERS:**

- $\bigcirc$  (4) 3/8 x 1 1/4"screw
  - (4) 3/8" fender washer
  - (4) 3/8" lock washer
  - (4) 3/8" hex nut
- (2) (2) 3/8 x 1 1/4" screw
  - (2) 3/8" flat washer
  - (2) 3/8" lock washer
  - (2) 3/8" hex nut

