

CATALOGUE NUMBER..... 217306  
APPLICATION..... Hyundai Excel Hbk & Sdn,  
Hyundai Scoupe,  
Mitsubishi Precis Hbk,  
HITCH CAPACITY ..... 2000 pounds gross trailer weight 200 pounds maximum tongue load  
OR the maximum load specified by the vehicle manufacturer;  
WHICHEVER IS LESS.

PLEASE NOTE: This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and regulation V.E.S.C. V-5.

1. Underneath the rear of the car locate the left and right tie down brackets(vertical plates), bolted to the frame rails. Remove both brackets (2 bolt/washer assemblies each) and return brackets to car owner for reinstallation should hitch ever be removed. Note: these existing bolt/washer assemblies will be reinstalled to secure hitch and rear bumper to frame.
2. This hitch fastens to car frame where brackets were just removed. Lift hitch into position above exhaust pipe and attach to car frame using existing fasteners ①. Refer to diagram. To ease installation, temporarily lower exhaust by disconnecting rearmost exhaust hangers.
3. Final tighten fasteners as specified on reverse of these instructions. Reconnect rearmost exhaust hangers. Recheck all fasteners occasionally for tightness.

FASTENERS:

- ① (4) 10 or 12mm bolt/washer assembly (existing)

