

CATALOG NUMBER.....247217  
 APPLICATION.....Mazda MX-3,  
 HITCH CAPACITY.....2000 pounds gross trailer weight 200 pounds maximum tongue load  
 OR the maximum load specified by the vehicle manufacturer;  
 WHICHEVER IS LESS.

- PLEASE NOTE: A. This hitch features a removable ball mount. This hitch is not intended for use as a weight distributing hitch. Before towing, the hitch pin and retainer clip MUST be in place securing ball mount to receiver.
- B. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and regulation V.E.S.C. V-5.
1. Under the rear of the car locate the tie down brackets (vertical plate with slot) joined to left and right frame rails.
  2. Work hitch into position on car over the exhaust extension and inside left tie down and outside right (passenger) tie down bracket. It may be necessary to temporarily release rear exhaust hangers. Install fasteners ② and adjust hitch in tie down slots until tabs on hitch end bracket fit flush against car floor.
  3. After clearing inside of car at holes ①, drill holes ① for 3/8" diameter screws through car floor. It may be necessary to mark for holes and lower hitch to drill holes.
  4. Install fasteners ① as shown. Be certain to use reinforcements plate (#471) under screw inside car opposite hitch. Make certain hitch is fitting flush at car floor. Final tighten all fasteners as specified on reverse of these instructions. Replace exhaust hangers if they were removed. Recheck all fasteners occasionally for tightness.

## FASTENERS:

- |                                |                      |
|--------------------------------|----------------------|
| ① (2) 3/8" x 1 1/2" screw      | ② (2) 5/8 x 2" screw |
| (2) 3/8" lock washer           | (2) 5/8" flat washer |
| (2) 3/8" hex nut               | (2) 5/8" lock washer |
| (2) reinforcement plate (#471) | (2) 5/8" hex nut     |

