

CATALOG NUMBER.....**247224**
 APPLICATION.....Porsche 924 and 944, all cars with
 exposed metal rear bumper,
 HITCH CAPACITY..... 1000 pounds gross trailer weight 100 pounds maximum tongue load
 OR the maximum load specified by the vehicle manufacturer;
 WHICHEVER IS LESS.

PLEASE NOTE: A. This hitch features a removable ball mount. This hitch is not intended for use as a weight distributing hitch. Before towing, the hitch pin and retainer clip **MUST** be in place securing ball mount to receiver.
 B. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and regulation V.E.S.C. V-5.

1. Remove all material in the spare tire well that might be damaged by drilling for the hitch.
2. Position the hitch under car's rear bumper and against body lip as shown in the diagram. If car has "aero" panel, hitch passes over panel. Make sure the hitch is centered and square with the car and use hitch as a template to mark bumper and body lip for screw holes.
3. Centerpunch and drill bumper and body lip for fasteners ① and ②.
4. Install the hitch as shown using fasteners ① and ② arranged as shown. Be certain to use backing plate (#354) inside spare tire well opposite hitch.
5. Final tighten all fasteners as specified on reverse of these instructions. Recheck all fasteners occasionally for tightness.

FASTENERS:

- ① (2) 3/8 x 2" screw
 (2) 3/8" lock washer
 (2) 3/8" hex nut
 (1) backing plate (#354)
- ② (2) 3/8 x 1 1/2" screw
 (2) 3/8" flat washer
 (2) 3/8" lock washer
 (2) 3/8" hex nut

