

# TRAILER HITCH MOUNTING INSTRUCTIONS

CATALOG NUMBER ..... 247254 .....  
APPLICATION ..... Infiniti J-30, Sedan,  
HITCH CAPACITY ..... 2000 pounds gross trailer weight 200 pounds maximum tongue load  
OR the maximum load specified by the vehicle manufacturer;  
WHICHEVER IS LESS.

PLEASE NOTE: A. This hitch features a removable ball mount. This hitch is not intended for use as a weight distributing hitch. Before towing, the hitch pin and retainer clip MUST be in place securing ball mount to receiver.  
B. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and regulation V.E.S.C. V-5.

1. Under the rear of car locate the left and right frame rails (box section running front/back). Remove the tie down brackets fastened near the rear of each rail (10mm screws). Return brackets and screws to vehicle's owner for reinstallation should hitch ever be removed.

OPTIONAL: Remove rear exhaust hangers temporarily for ease of placing hitch.

2. Place the hitch up to the bottom of frame rails matching the hitch holes with holes in frame rails and bracket (right side). Hitch is to pass over the car's exhaust "tips" on left (driver's side).
3. Bolt the hitch to car's frame rails using fasteners ① and ②. Fasteners ② are used on right side only at additional frame "tab".
4. Final tighten fasteners as specified on reverse of these instructions. Recheck all fasteners occasionally for tightness.

## FASTENERS:

- ① (4) 10 x 1.25 x 30mm screw  
(4) 3/8" flat washer  
(4) 7/16" lock washer
- ② (1) 7/16 x 1 1/2" screw  
(2) 7/16" flat washer  
(1) 7/16" lock washer  
(1) 7/16" hex nut

