

CATALOGUE NUMBER
 APPLICATION.....Saab 900, Hatchback, **247264** —
 Saab 900, Convertible,
 HITCH CAPACITY.....2000 pounds gross trailer weight 200 pounds maximum tongue load OR the
 maximum load specified by the vehicle manufacturer; WHICHEVER IS
 LESS.

PLEASE NOTE: A. This hitch features a removable ball mount. This hitch is not intended for use as a weight distributing hitch. Before towing, the hitch pin and retainer clip **MUST** be in place securing ball mount to receiver.
 B. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and regulation V.E.S.C. V-5.
 C. **WARNING - STANDARD SPLICING OF TRAILER WIRING AT CAR'S TAIL LIGHTS MAY SERIOUSLY DAMAGE LIGHTING SYSTEM. SEE SAAB DEALER FOR TRAILER LIGHT WIRING INSTRUCTIONS.**

1. Temporarily remove rear bumper. Unbolt two tie down brackets in trunk at rear wall and remove two plastic "nuts" holding plastic panel in place and remove panel. Inside rear body panel remove four nuts using 17mm wrench. Pull bumper fascia out at tire well and slide bumper rearward, use care with bumper to prevent scratches.
2. Remove any existing fasteners from holes in center of bumper beam. Fasten hitch to bumper using fasteners ①. Final tighten all fasteners as specified on reverse of these instructions now. Reinstall bumper.
3. Remove spare tire and using hitch as template drill tire well four places to accept 3/8" diameter screws of fasteners ②. Install fasteners and final tighten as specified on reverse of these instructions. Recheck all fasteners occasionally for tightness.

FASTENERS:

- ① (3) 10 x 1.5 x 30mm screw
 (3) 7/16" lock washer
- ② (4) 3/8 x 1 1/4" screw
 (4) 3/8" fender washer
 (4) 3/8" lock washer
 (4) 3/8" hex nut

