DATE: 03:01:99

CATALOG NUMBER 367214

bundle inside passenger side frame rail.

USE BALL MOUNT: #55061

**FASTENERS:** 

APPLICATION ..... .....Volkswagen Eurovan, Van.

maximum load specified by the vehicle manufacturer; WHICHEVER IS LESS

NOTES: A. This hitch features a removable ball mount. This hitch is not intended for use as a weight distributing hitch. Before towing, the hitch pin and retainer clip MUST be in place securing ball mount to receiver.

- systems of the state of New York and regulation V.E.S.C. V-5.
- B. This product complies with safety specifications and requirements for connecting devices and towing 1. This hitch is a three piece receiver design featuring a 1 1/4" square receiver and cross tube bolted to left and right
- frame plates. Frame plates bolt to existing weldnuts and holes in vertical section of frame rails and bumper brackets. One bracket mounted under rearmost bumper screw on passenger side is discarded. Temporarily remove spare tire, 2. On each side of vehicle, remove two bolts at location (1), attaching humper bracket to frame rail. Mount frame plate (without receiver assembly) to frame rails aligning rearmost holes with existing welcouts in bumper bracket. Loosely

install fasteners. The as shown in diagram below. Note: It may be necessary to remove plastic clips holding wire

3. Loosely install fasteners @ as shown below in forward holes of frame plate. Note: use hex nut on passenger side and

- handle nut (#1604) on driver's side where access is a problem. 4. Mount receiver assembly between frame plates and install fasteners. 3 as shown in diagram below.
- 5. Final tighten fasteners as specified on reverse of these instructions. Replace spare tire. Recheek all fasteners
  - occasionally for tightness.

