

U-HAUL TECH CTR. CUSTOM HITCH PROGRAM

HITCH INSTALLATION INSTRUCTIONS	HITCH # 24997
VEHICL: 2002 TOYOTA PRIUS HYBRID	Pg. 1
CLASS 1 (MAX. GROSS 1,500 LBS. / MAX. TONGUE 150 LBS.)	02/25/02
REQUIRES DRAW-TITE DRAWBAR : 3597	Aprox. Weight: 23 LBS. Install Time: 0.5 hrs.

1. Remove vehicle tie-downs from both frame rails and give to your hitch customer for reinstallation if Hitch is removed.
2. Lower exhaust at the rear of the vehicle by removing exhaust hanger above muffler.
3. Raise hitch in position aligning holes in hitch brackets with existing holes where tie-downs were removed in step 1.
4. Install new M10-1.25 x 25mm hex bolts with a 7/16" conical washer in each hole.
5. Torque M10 fasteners to 39 ft.-lbs.
6. Reinstall muffler hanger.

Give these instructions to your hitch customer.

HITCH MAINTENANCE

Inspect periodically to insure that fasteners remain tight, and that the hitch and vehicle structure is intact and free of rust/corrosion or evidence of structural failure. If you have questions or comments regarding this custom hitch, call the **U-Haul Technical Center** at **1-800-223-6218**.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and V.E.S.C. regulation V-5

QTY.	DESCRIPTION OF HARDWARE
4	M10-1.25 x 25mm Hex Bolt
4	7/16" Conical Washer