

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 3500 LBS. TRAILER WEIGHT & 300 LBS. TONGUE WEIGHT.

*****DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.*****


WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS.

**** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY****

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

| Parts List | | | |
|------------|-----|---------------------|--------------|
| ITEM | QTY | PART NUMBER | DESCRIPTION |
| 1 | 6 | M12 - 1.25 x 40 HEX | HEX TAP BOLT |
| 2 | 6 | 1/2" | LOCK WASHER |
| 3 | 6 | 7/16 | WASHER |

EXISTING WELD NUTS
(BOTH SIDES)



HITCH WEIGHT: 23 LBS.

INSTALL TIME

PROFESSIONAL: 30 MINUTES

NOVICE (DIY): 60 MINUTES

INSTALL NOTES:

NO DRILLING REQUIRED

INSTALLATION STEPS

- 1) Under the rear of the car, locate the exhaust mufflers on the left and right sides of the car. Mufflers are supported at the rear of the vehicle by flexible supports and brackets bolted into the chassis with three 12mm screws per bracket.
- 2) Temporarily remove these brackets from the chassis at the left and right sides of the car. Position the hitch on the vehicle at the same mounting points. Re-mount these brackets at the bottom of the hitch brackets on both sides of the vehicle. Mount the hitch using fasteners provided.
- 3) Torque all 12mm fasteners to 65 lb-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.