

U-HAUL TECH CTR. CUSTOM HITCH HITCH INSTALLATION INSTRUCTIONS

PROGRAM

HITCH # 75934

| | |
|--|--|
| VEHICLE: 1962-64 CHRYSLER 300 1960-61 CHRYSLER WINDSOR 1961-64 CHRYSLER NEWPORT 1963-64 CHRYSLER NEW YORKER CLASS 3 (MAX. GROSS 5,000 LBS. / MAX. TONGUE 500 LBS.) | Pg. 1 of 1 |
| | 10/1/98 |
| | Aprox. Weight: 55 lbs. Install Time: 0.8 hrs. |

1. Raise hitch into position aligning rear most hole in frame with rear most hole in each hitch bracket.
2. Being careful not to move hitch, drill a 1/2" hole up through the center hole in the hitch bracket and into the frame.
3. Lower the hitch and enlarge the 2nd and 4th existing (factory) hole from the rear in the bottom of frame to 3/4".
4. Insert the 7/16" carriage bolts with a 3/16" X 1" X 2" reinforcing plate into the enlarged hole on the inside of the frame and down into the holes that will align with the hitch brackets.
5. Raise hitch into position being careful not to push bolts back up into the frame.
6. Install a 7/16" conical washer and a 7/16" hex nut on each bolt.
7. Torque 7/16" fasteners to 50-ft. lbs.

Give these instructions to your hitch customer.

HITCH MAINTENANCE

Inspect periodically to insure that fasteners remain tight, and that the hitch and vehicle structures are intact and free of rust/corrosion or evidence of structural failure. If you have questions or comments regarding this custom hitch, call the **U-Haul Technical Center** at **1-800-223-6218**.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and V.E.S.C. regulation V-5.

| QTY. | DESCRIPTION OF HARDWARE |
|------|-----------------------------------|
| 6 | 7/16" X 1 3/4" CARRIAGE BOLT |
| 6 | 7/16" CONICAL WASHER |
| 6 | 7/16" HEX NUT |
| 6 | 3/16" x 1" x 2" REINFORCING PLATE |